

Contactors and Contactor Assemblies

3RT1 Contactors

SIRIUS



Accessories for contactors

Selection and ordering data



3RH19 21-1F...



3RH19 21-2F...



3RH19 21-1C...



3RH19 21-2C...



3RH19 21-1LA...



3RH19 21-1MA...

For contactors	Rated operational current ²⁾ NEMA A600 / Q600	Auxiliary contacts				Screw connection		Cage Clamp connection		Weight approx.	Pack.
		Ident. no.	Design				Order No.	List Price \$	Order No.		
Type											kg
			NO	NC	NO	NC					

Auxiliary switch blocks for snapping onto the front acc. to EN 50 005

Sizes S0 to S12¹⁾

4-pole auxiliary switch blocks

3RT10 2,	40	4	-	-	-	3RH19 21-1FA40	3RH19 21-2FA40	0.065	1 unit
3RT1. 3 to	31	3	1	-	-	3RH19 21-1FA31	3RH19 21-2FA31		
3RT1. 7,	22	2	2	-	-	3RH19 21-1FA22	3RH19 21-2FA22		
3RT11	04	-	4	-	-	3RH19 21-1FA04	3RH19 21-2FA04		
	22 U	-	-	2	2	3RH19 21-1FC22	3RH19 21-2FC22		

Single-pole auxiliary switch blocks acc. to EN 50 005 and EN 50 012

3RT1. 2 to	-	1	-	-	-	3RH19 21-1CA10	3RH19 21-2CA10	0.015	1 unit
3RT1. 7,	-	-	1	-	-	3RH19 21-1CA01	3RH19 21-2CA01		
3RT11	-	-	-	1	-	3RH19 21-1CD10	-		
	-	-	-	-	1	3RH19 21-1CD01	-		

2-pole auxiliary switch blocks with cable entry from one side

• Cable entry from above

3RT10 2,	-	1	1	-	-	3RH19 21-1LA11	-	0.065	1 unit
3RT1. 3 to	-	2	-	-	-	3RH19 21-1LA20	-		
3RT1. 7,	-	-	2	-	-	3RH19 21-1LA02	-		
3RT11	-	-	-	-	-	-	-		

• Cable entry from below

	-	1	1	-	-	3RH19 21-1MA11	-	0.065	1 unit
	-	2	-	-	-	3RH19 21-1MA20	-		
	-	-	2	-	-	3RH19 21-1MA02	-		

EN50005 and EN50012 designate the markings of the auxiliary terminal numbers.
For position of the terminals see pages 2/166-169.
For int. circuit diagrams see pages 2/156-160.

1) Exception: 3RT16.

2) UL ratings, Appendix page 19/7.