Finish

Select Operating Head (if desired)

All operating heads can be attached in 4 directions, in 90° increments.

Operating Heads

Plastic Operating Head	Description	Catalog Number	Price
Roller Lever			
	Short	LS-XLS	18
	Long	LS-XL	18
	Large	LS-XLB	18
Adjustable Roller Leve	ers		
3)	18 mm diameter	LS-XRLA	35
6	30 mm diameter	LS-XRLA30	35
	40 mm diameter	LS-XRLA40	35
0	40 mm diameter (rubber)	LS-XRLA40R	35

	T			
Plastic Operating Head	Description	Catalog Number	Price	
Angled Roller Lever				
		LS-XLA	18	
Rotary Lever				
6		LS-XRL	35	
Roller Plunger				
		LS-XP	18	
	for enclosure mounting	LS-XZRS	45	
Rounded Plunger				
	for enclosure mounting	LS-XZS	40	
Actuating Rods				
	Plastic Rod	LS-XRR	35	
	Metal Rod	LS-XRRM	35	
		LS-XOR	35	
Spring Rod				
	For use with Snap- Action Contacts only. Not for use as a safety switch.	LS-XS	35	
RMQ-Titan Adapter				
	For use with RMQ- Titan operators	M22-LS	5	