3RB2 / 3RB3 Solid-State Overload Relays



3RB20, 3RB21, 3RB30, 3RB31 up to 630A for standard applications

3RB20 solid-state overload relays and stand-alone installation $^{2)3)},$ CLASS 10 or CLASS 20 for direct mounting $^{1)2)}$

Features and technical specifications:

- Overload protection, phase failure protection and unbalance protection
- Internal power supply
- Auxiliary contacts 1 NO + 1 NC

- Manual and automatic RESET
- Switch position indicator
- TEST function and self-monitoring

	Size Contactor ⁴⁾	Set current value of the inverse-time delayed overload trip		Screw Terminal Order Number		Spring Loaded Terminal Order Number		Weight per PU approx.
		А						kg
Size S00 ¹⁾ 3RB30 16-1RB0	S00	0.1 0.4 0.32 1.25 1 4 3 12 4 16		3RB30 16-□F 3RB30 16-□N 3RB30 16-□F 3RB30 16-□S 3RB30 16-□T	NB0 PB0 SB0	3RB30 16-□R 3RB30 16-□N 3RB30 16-□P 3RB30 16-□S 3RB30 16-□T	IEO PEO SEO	0.172 0.172 0.172 0.172 0.172
Size S0 ¹⁾	S0	0.1 0.4 0.32 1.25 1 4 3 12 6 25 10 40		3RB30 26-□F 3RB30 26-□F 3RB30 26-□F 3RB30 26-□F 3RB30 26-□F	NB0 PB0 SB0 QB0	3RB30 26-□R 3RB30 26-□N 3RB30 26-□P 3RB30 26-□S 3RB30 26-□C 3RB30 26-□V	IEO PEO SEO REO	0.250 0.250 0.250 0.250 0.250 0.250
Size S2 1)3)5)	S2	12 50 20 80	with busbar with pass through CT's with busbar	3RB30 36-□L 3RB30 36-□L 3RB30 36-□L	VB0 :	3RB30 36-□U 3RB30 36-□U 3RB30 36-□V	JX1	0.360 0.230 0.360
3RB30 36-1UB0			with pass through CT's	3RB30 36-□V	VW1 ;	3RB30 36-□V	VX1	0.230
Size S3 ¹⁾³⁾⁵⁾	S3	12.5 50	with busbar with pass through CT's	3RB30 46-□L 3RB30 46-□L		3RB30 46-□U 3RB30 46-□U		0.560 0.450
3RB30 46-1XB0		32 115	with busbar with pass through CT's	3RB30 46-□) 3RB30 46-□)		3RB30 46-□X 3RB30 46-□X		0.560 0.450
Size S6 ²⁾⁵⁾	S6	50 200	with busbar with pass through CT's	3RB20 56-□F 3RB20 56-□F		3RB20 56-□F 3RB20 56-□F		1.030 0.690
3RB20 56-1FW2 Size S10/S12 ²)	\$10/\$12 and size 14 (3TF68/ 3TF69)	55 250 160 630	with busbar with busbar	3RB20 66-□ 0 3RB20 66-□ N		3RB20 66-□G 3RB20 66-□N		1.820 1.820
3RB20 66-1MC2	311 09)				Class 20 Class 10		Class 20 Class 10	

- 1) The relays with an Order No. ending with "0" are designed for direct mounting to the contactor. With the matching terminal brackets (see Accessories) the sizes S00 to S3 can also be installed as stand-alone units.
- 2) The relays with an Order No. ending with "2" are designed for direct mounting and stand-alone installation. For 3TF68/3TF69 contactors, direct mounting is not possible.
- 3) The relays with an Order No. ending with "1" are designed for stand-alone installation.
- 4) Observe maximum rated operational current of the devices.
- 5) The relays with an Order No. with "X" in 10th position are equipped with a straight-through transformer.

For accessories, see pages 3/49-3/50. For description, see pages 3/18-3/20. For technical data, see pages 3/24-3/29. For dimension drawings, see page 3/30. For schematic diagrams, see page 3/31.





3RB30 16, 3RB31 13, size S00






3RB30 26, 3RB31 23, size S0








3RB30 36, 3RB31 33, size S2




3RB30 46, 3RB31 43, size S3









3RB20 66, 3RB21 63, size S10/S12



3RB30 36, 3RB31 33, size S2 with straight-through transformer



3RB30 46, 3RB31 43, size S3 with straight-through transformer



3RB20 56, 3RB21 53, size S6 with straight-through transformer